


Disassembly and Recycling Instructions

Lilly 9121


Tools Required:




Safety Glasses



Metric Allen
Wrenches



Hammer



Wrenches/Ratchet

1. Remove Casters/Glides from frame. Recycle Casters/Glides
2. Separate the Shell from the wood legs then Discard.
3. Separate the Wood from the frame.
4. After all parts are removed then recycle the frame.



Shell

Plywood, Polyurethane foam



Frame

Cold Rolled Steel



Wood Leg

Wood



Casters, Glides

Polypropylene, Nylon, ABS



= Recyclable Material Content